INSTALLATION INSTRUCTIONS

CONCORD EDGE ON HIGH-RATE SIDE BAND LIQUID AND NH3 OPENERS



2110 Park Avenue Brandon, Manitoba, Canada R7B 0R9

Website: www.atomjet.com Email: agriculture@atomjet.com Phone: 1.204.728.8590

Fax: 1.204.726.5734
Toll Free: 1.800.573.5048

IMPORTANT WARRANTY/GUARANTEE INFORMATION DO NOT DESTROY

Any claims under the guarantee must be COMPLETED BY OCTOBER 31 IN THE YEAR OF PURCHASE to qualify for a full refund. To satisfy a claim, Atom-Jet Industries must be given the opportunity during the seeding season to rectify the problem or issue, if NOT THE GUARANTEE IS NULL AND VOID. Wear under normal use is not covered by warranty/guarantee.

To activate your warranty registration, scan this QR code using the application on your mobile device and fill out the online form. Upon receipt of the completed form, we will send you a free pair of Atom-Jet work gloves.



WARRANTY IS TO BE COMPLETED BY OCTOBER 31 IN THE YEAR OF PURCHASE. The openers will either be Replaced or Repaired during this period. If you need to return an opener for warranty, please enclose your name, the farm name, address, phone number with area code, dealer purchased from, number of openers purchased, and the date of purchase. Please enclose copy of original invoice. Inclusion of the information will significantly speed up your warranty claim.



Opener Installation

1) Bolt openers to the shank using the provided ½" x 2 ½" bolts and nuts. Install the spacer shank between the opener and the shank. Mount the openers with the seed chute pointed to the center of the drill (see Figure 2 below).




Figure 1: Bolt opener to shank

High-rate side band liquid and NH3 openers must be installed with the seed chutes oriented to the center of the drill. A left opener will have the seed chute on the left side as seen in Figure 2.





Figure 2: Seed chute on "left" opener

Mounting your openers on the correct side of the drill will reduce the chances of plugging while turning with the drill in the ground. A "left" opener will have the seed chute pointed to the left when viewed from the back. In Figure 3, the arrows represent the direction of the seed chute.

Right opener is mounted on the left side of the drill



Left opener is mounted on the right side of the drill

Figure 3: Opener orientation

2) Install the FOCUS STRIP by inserting it down through the seed tube and hooking it over the rear center of the seed tube in the hose clamp slot.




Figure 4: Install focus strip

3) Loosely slide the #20 hose clamp over the seed delivery tube then insert seed hose into the opener. To ensure seed does not flow past the focus strip, push the seed tube to where the opener narrows.




Figure 5: Install seed hose

It is very important to firmly secure the seed hose and FOCUS STRIP in their proper positions with the supplied #20 hose clamp. If the focus strip is loose, a pair of water pump pliers can be used to close the lower portion of the seed tube below the hose clamp slot. With the seed hose and focus strip securely in place, use your finger from the back of the opener to bend the focus strip forward to direct the seed to the front of the opener. This will ensure the seed is properly placed on firm soil.

Our openers are designed to allow hoses of different diameters. Hose bushings will be required for ¾" ID hoses. Short pieces of delivery hose sliced vertically and slipped over the delivery hose make good bushings. If desired, a bushing can be purchased through Atom-Jet: part OP-CB15 TUBE SPACER.

4) Install the fertilizer tube on the stainless steel tube. Slide the fertilizer tube over the stainless steel tube and secure with the supplied hose clamp. To prevent dislodging of the line, zip tie the fertilizer hose to the seed hose and drill frame.




Figure 6: Install fertilizer hose

Opener Maintenance

Atom-Jet openers are designed to be tough, durable, and reliable in all soil conditions. To extend the life of your openers even further, follow these steps:

- 1) Exchange openers from the wheel tracks with other areas of the drill or cultivator.
- 2) Maintain hard surfacing on the openers by building up the areas that were hard surfaced at the factory. Detailed instructions on how to do this are on the back page. Hard surface welding sticks and hard surface wire can be purchased through your local welding supply store.

Hard Surfacing




Figure 7: Hard surface paths

One of the reasons we chose steel to build our openers is the ease with which they can be maintained. The following steps are for re-building the hard surface weld beads:

- 1) Maintain the hard surfacing on the openers by building up the areas we have hard surfaced in the factory. Clean off the openers and work on at least ten openers at a time. The idea is to minimize the heat build-up in the opener, preventing any damage to the carbide.
- 2) Follow these steps:
 - a. Starting 1/8" away from the carbide, do PATH #1 on all openers.
 - b. Then, do PATH #2 on the skirting of all openers. It may help to clamp a piece of steel inside the boot plate to give backing to the weld and to act as a heat sink.
 - c. Next, do PATH #3 on the tube shield.
 - d. Hold the opener so the wing is flat. Starting $\frac{1}{8}$ " away from the carbide, do PATH #4 on the wing.
 - e. Turn the openers over and do PATHS #5 to #8 following the same method as the first side.
 - f. Finally, hold the opener so the point faces up. Starting 1/8" away from the carbide, do the paths marked #9 on all openers.
- 3) Atom-Jet Industries regularly performs this process for many customers. Call today for a quote at 1-800-573-5048.